

EXTERNAL LINKS

HD67601-485-A1



QR of Manual

[www.adfweb.com/download/
filefold/MN67601_ENG.pdf](http://www.adfweb.com/download/filefold/MN67601_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67601-485-A1_ENG.pdf](http://www.adfweb.com/download/filefold/BS67601-485-A1_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67601.zip](http://www.adfweb.com/download/filefold/SW67601.zip)

HD67601-485-A1

BOX SHEET

PROFINET / Serial - Converter

Box Sheet for Order code: HD67601-485-A1
Document code: BS67601-485-A1
V1.003



ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67601-485-A1

Dip-Switch A:


-Dip1 – Functioning Mode



= Normal



= Boot



Led1:

Green ON

Led2:

Yellow MT

Led3:

Red BF

Led4:

Red SF

Connector3:

Ethernet1 Port (RJ45 Plug)

Led6:

Green Ethernet2 Tx

Connector4:

Ethernet2 Port (RJ45 Plug)

Dip-Switch B:

-Dip1 – RS485 Termination Resistor




= Open



= 120 Ohm

-Dip2 – Not used



Connector2:

RS485 (Isolated port)

S = Shield* (to Isolated Ground)

B = Negative wire

A = Positive wire

Connector1:

Power Supply port

0V = Ground

+V = Positive wire

V AC: min 8V ; max 24V

V DC: min 12V ; max 35V

Order code: HD67601-485-A1