



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67629\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67629_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67629-B2\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67629-B2_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67629.zip](http://www.adfweb.com/download/filefold/SW67629.zip)

**HD67629-B2**

# BOX SHEET

## S7comm / MQTT - Converter

Box Sheet for Order code: HD67629-B2  
Document code: BS67629-B2  
V1.000



**ADFweb.com srl**  
Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67629-B2

## Dip-Switch A:


-Dip1 - Functioning Mode



= Normal Mode



= Boot Mode




**Led1:**  
Green  
Device state

**Led2:**  
Yellow  
S7comm comm.

**Led3:**  
Yellow  
MQTT comm.

**Led4:**  
Yellow  
Error state



**Connector3:**  
Ethernet Port  
(RJ45 Plug)

**Led5:**  
Green  
Link Ethernet



**Connector1:**  
Power Supply

0V = Ground

+V = Positive wire

V AC: min 8V ; max 24V

V DC: min 12V ; max 35V

Order code: HD67629-B2