


J1939 / PROFIBUS Slave - Converter

To obtain the complete manual please go to www.adfweb.com/download/filefold/MN67437 ENG.pdf

To obtain the new version of this box sheet please go to www.adfweb.com/download/filefold/BS67437-E7x ENG.pdf

CONNECTION SCHEME:



CONFIGURATION SOFTWARE:

For setting up the device you need the software named SW67437. To obtain software please go to

www.adfweb.com/download/filefold/SW67437.zip

ADFweb.com s.r.l. www.adfweb.com support@adfweb.com



Page 1/1 info@adfweb.com