

## EXTERNAL LINKS

HD67022-B2



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67022\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67022_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67022-B2\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67022-B2_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67022.zip](http://www.adfweb.com/download/filefold/SW67022.zip)

**HD67022-B2**

# BOX SHEET

**M-Bus / RS485 – Converter**

Box Sheet for order code: HD67022-B2  
Document code: BS6702-B2  
V1.002




**ADFweb.com srl**

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67022-B2



Order code: HD67022-B2