

## EXTERNAL LINKS

HD67029-232-B2-xxx



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67029\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67029_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67029-232-B2-xxx\\_  
ENG.pdf](http://www.adfweb.com/download/filefold/BS67029-232-B2-xxx_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67029.zip](http://www.adfweb.com/download/filefold/SW67029.zip)

HD67029-232-B2-xxx

# BOX SHEET

**M-Bus master / Modbus slave - Converter**

Box Sheet for Order code: HD67029-232-B2-xxx

Document code: BS67029-232-B2-xxx

V1.004




**ADFweb.com srl**

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67029-232-B2-xxx



Order code: HD67029-232-B2-xxx