

EXTERNAL LINKS

HD67141-B2



QR of Manual

[www.adfweb.com/download/
filefold/MN67141_ENG.pdf](http://www.adfweb.com/download/filefold/MN67141_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67141-B2_ENG.pdf](http://www.adfweb.com/download/filefold/BS67141-B2_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67141.zip](http://www.adfweb.com/download/filefold/SW67141.zip)

HD67141-B2

BOX SHEET

DeviceNet Slave / Modbus Master Converter

Box Sheet for Order code: HD67141-B2
Document code: BS67141-B2
V1.002




ADFweb.com srl
Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67141-B2



Order code: HD67141-B2