



QR of Manual

[www.adfweb.com/download/
filefold/MN67176_ENG.pdf](http://www.adfweb.com/download/filefold/MN67176_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67176-A1_ENG.pdf](http://www.adfweb.com/download/filefold/BS67176-A1_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67176.zip](http://www.adfweb.com/download/filefold/SW67176.zip)

HD67176-A1

BOX SHEET

**Modbus TCP Slave / SNMP Manager
Converter**

Box Sheet for Order code: HD67176-A1
Document code: BS67176-A1
V1.002



ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67176-A1

Dip-Switch A:

-Dip1 - Functioning Mode



= Normal



= Boot



Led1:

Green
Modbus TCP comm.

Led2:

Green
Device state

Led3:

Green
Ethernet1 Tx

Connector3:

Ethernet1 port
(RJ45 Plug)

Led4:

Green
Ethernet2 Tx

Connector4:

Ethernet2 port
(RJ45 Plug)

Connector1:

Power Supply port

0V = Ground

+V = Positive wire

V AC: min 8V ; max 24V

V DC: min 12V ; max 35V

Order code: HD67176-A1