



QR of Manual

[www.adfweb.com/download/
filefold/MN67431_ENG.pdf](http://www.adfweb.com/download/filefold/MN67431_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67431-E4X_ENG.pdf](http://www.adfweb.com/download/filefold/BS67431-E4X_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67431.zip](http://www.adfweb.com/download/filefold/SW67431.zip)

HD67431-E4X-xxx

BOX SHEET

J1939 / Modbus Master - Converter

Box Sheet for Order code: HD67431-E4x-xxx
Document code: BS67431-E4x
V1.200



ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67431-E4X-xxx

Connector3:

CAN port

Hi = High wire

Lo = Low wire

ShI0 = Shield (to Isolated Ground)



Connector2:

RS485 port

+ = Positive wire

- = Negative wire

ShI1 = Shield (to Isolated Ground)



Connector1:


Power Supply port

0V = Ground

+V = Positive wire

V AC: min 8V ; max 26V

V DC: min 10V ; max 40V



Connector4:
USB port

Led 1:
Green
Device State

Led 2:
Green
CAN comm.

Led 3:
Yellow
Boot Mode

Led 4:
Green
RS485 comm.

Order code: HD67431-E4X-xxx