



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67672\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67672_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67672-IP-4\\_A1\\_  
ENG.pdf](http://www.adfweb.com/download/filefold/BS67672-IP-4_A1_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67672.zip](http://www.adfweb.com/download/filefold/SW67672.zip)

**HD67672-IP-4-A1**

# BOX SHEET

**BACnet/IP Slave / Modbus Slave - Converter**

Box Sheet for Order code: HD67672-IP-4-A1  
Document code: BS67672-IP-4-A1  
V1.002




**ADFweb.com srl**

Strada Nuova, 17, IT-31010 Marenco di Piave, Treviso - Italy

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67672-IP-4-A1



Order code: HD67672-IP-4-A1