

## RS485 / Single-Mode Optic Fiber - Converter


To obtain the complete manual please go to

[www.adfweb.com/download/filefold/MN67701\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67701_ENG.pdf)

To obtain the new version of this box sheet please go to

[www.adfweb.com/download/filefold/BS67702-4-0\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67702-4-0_ENG.pdf)

### CONNECTION SCHEME:



### CONFIGURATION SOFTWARE:

For setting up the device you need the software named SW67701.

To obtain this software please go to

[www.adfweb.com/download/filefold/SW67701.zip](http://www.adfweb.com/download/filefold/SW67701.zip)

ADFweb.com s.r.l.  
 www.adfweb.com  
 support@adfweb.com

Manual



Box-Sheet



Software

