

## EXTERNAL LINKS

HD67735-A1



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67735\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67735_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67735-A1\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67735-A1_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67735.zip](http://www.adfweb.com/download/filefold/SW67735.zip)

**HD67735-A1**

# BOX SHEET

**IEC 61850 Server / Modbus TCP Master  
Converter**

Box Sheet for Order code: HD67735-A1  
Document code: BS67735-A1  
V1.001



**ADFweb.com srl**

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

[www.ADFweb.com](http://www.ADFweb.com)

# CONNECTION SCHEME

Order code: HD67735-A1

## Dip-Switch A:


-Dip1 – Functioning Mode



= Normal



= Boot



## Led1:

Green  
ON

## Led2:

Green  
Device state

## Led3:

Green  
IEC 61850 comm.

## Led4:

Green  
Modbus comm.

## Led5:

Green  
Ethernet1 Tx

Rail DIN  
Clamp

**Connector3:**  
Ethernet1 port  
(RJ45 Plug)

**Led6:**  
Green  
Ethernet2 Tx

**Connector4:**  
Ethernet2 port  
(RJ45 Plug)

## Connector1:

Power Supply port

0V = Ground

+V = Positive wire

V AC: min 8V ; max 24V

V DC: min 12V ; max 35V

Order code: HD67735-A1