



QR of Manual

[www.adfweb.com/download/
filefold/MN67863_ENG.pdf](http://www.adfweb.com/download/filefold/MN67863_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67863-A1-2B_ENG.pdf](http://www.adfweb.com/download/filefold/BS67863-A1-2B_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67863.zip](http://www.adfweb.com/download/filefold/SW67863.zip)

HD67863-A1-2B

BOX SHEET

IO-Link / Modbus TCP Slave - Converter

Box Sheet for Order code: HD67863-A1-2B

Document code: BS67863-A1-2B

V1.000




ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67863-A1-2B



Order code: HD67863-A1-2B