

EXTERNAL LINKS

HD67876-A1-2A



QR of Manual

[www.adfweb.com/download/
filefold/MN67876_ENG.pdf](http://www.adfweb.com/download/filefold/MN67876_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67876-A1-2A_ENG.pdf](http://www.adfweb.com/download/filefold/BS67876-A1-2A_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67876.zip](http://www.adfweb.com/download/filefold/SW67876.zip)

HD67876-A1-2A

BOX SHEET

IO-Link / PROFINET slave – Converter

Box Sheet for Order code: HD67876-A1-2A

Document code: BS67876-A1-2A

V1.000




ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy

www.ADFweb.com

CONNECTION SCHEME

Order code: HD67876-A1-2A



Order code: HD67876-A1-2A