



QR of Manual

---

[www.adfweb.com/download/  
filefold/MN67937\\_ENG.pdf](http://www.adfweb.com/download/filefold/MN67937_ENG.pdf)



QR of Box-Sheet

---

[www.adfweb.com/download/  
filefold/BS67937-MSTP-B2\\_ENG.pdf](http://www.adfweb.com/download/filefold/BS67937-MSTP-B2_ENG.pdf)



QR of Software

---

[www.adfweb.com/download/  
filefold/SW67937.zip](http://www.adfweb.com/download/filefold/SW67937.zip)

# BOX SHEET

**BACnet MS/TP Master / MQTT - Converter**

Box Sheet for Order code: HD67937-MSTP-B2  
Document code: BS67937-MSTP-B2  
V1.001




**ADFweb.com srl**

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy


# CONNECTION SCHEME

Order code: HD67937-MSTP-B2

**Dip-Switch B:**  
-Dip1 – Termination RS485 line



**Dip-Switch A:**  
-Dip1 – Functioning Mode




**Led1:**  
Green  
Device state

**Led2:**  
Yellow  
Serial comm.

**Led3:**  
Yellow  
MQTT status


**Led4:**  
Yellow  
Comm. error



**Connector3:**  
Ethernet Port  
(RJ45 Plug)

**Led5:**  
Green  
Link Ethernet

**Connector2:**  
DALI Port  
(Unpolarized)



**Connector4:**  
RS485 port

S = Shield (to Isolated Ground)  
- = Negative wire  
+ = Positive wire

**Connector1:**  
Power Supply

0V = Ground  
+V = Positive wire

V AC: min 8V ; max 24V  
V DC: min 12V ; max 35V