

## Can to Modbus Server TCP

To obtain the complete manual please go to

www.adfweb.com/download


or

www.adfweb.com/download/filefold/Can Modbus Server TCP MN67015 ENG.pdf

To obtain the new version of this box sheet please go to

http://www.adfweb.com/download/filefold/BS67015 ENG.pdf

## **CONNECTION SCHEME**



## THE CONFIGURATION SOFTWARE:

For setting up the device you need a the software named SW7015. To obtain this software please go to

http://www.adfweb.com/download


or

http://www.adfweb.com/download/filefold/SW67015.zip

## **CHARACTERISTICS OF THE CABLES:**

The connection from RS232 socket to a serial port must be made with a NULL MODEM cable (a serial cable where the pins 2 and 3 are crossed).

It is recommended that the RS232C Cable not exceed 15 meters.



ADFweb.com s.r.l. www.adfweb.com info@adfweb.com support@adfweb.com