

## BACnet PTP Master / PROFINET slave - Converter


To obtain the complete manual please go to:

www.adfweb.com/download/filefold/MN67719 ENG.pdf

To obtain the new version of this box sheet please go to:

www.adfweb.com/download/filefold/BS67719-PTP-B2\_ENG.pdf

## **CONNECTION SCHEME:**



## **CONFIGURATION SOFTWARE:**

For setting up the device you need the software named SW67719. To obtain this software please go to:

www.adfweb.com/download/filefold/SW67719.zip

ADFweb.com s.r.l. www.adfweb.com support@adfweb.com

Manual 

回去

Box-Sheet



Software



info@adfweb.com