



QR of Manual

[www.adfweb.com/download/
filefold/MN67681_ENG.pdf](http://www.adfweb.com/download/filefold/MN67681_ENG.pdf)



QR of Box-Sheet

[www.adfweb.com/download/
filefold/BS67681-IP-A1_ENG.pdf](http://www.adfweb.com/download/filefold/BS67681-IP-A1_ENG.pdf)



QR of Software

[www.adfweb.com/download/
filefold/SW67681.zip](http://www.adfweb.com/download/filefold/SW67681.zip)

HD67681-IP-A1

BOX SHEET

BACnet/IP / DeviceNet Slave – Converter

Box Sheet for Order code: HD67681-IP-A1
Document code: BS67681-IP-A1
V1.003



ADFweb.com srl

Strada Nuova, 17, IT-31010 Mareno di Piave, Treviso - Italy


www.ADFweb.com

CONNECTION SCHEME

Order code: HD67681-IP-A1

Dip-Switch A:

-Dip1 – Functioning Mode



Rail DIN Clamp

Led1:
Green
ON

Led2:
Green
Device State

Led3:
Green
DeviceNet comm.

Led4:
Green
BACnet comm.

Connector3:
Ethernet1 Port
(RJ45 Plug)

Led6:
Green
Ethernet2 Tx

Connector4:
Ethernet2 Port
(RJ45 Plug)

Dip-Switch B:

-Dip1 – CAN Termination Resistor



Connector2:
CAN port (Isolated port)

Hi = High wire
Shl = Shield* (to Isolated Ground)
Lo = Low wire

Connector1:

Power Supply port
0V = Ground
+V = Positive wire

V AC: min 8V ; max 24V
V DC: min 12V ; max 35V

Order code: HD67681-IP-A1